









Pro-Stitcher Tablet and Version information

Tablet Name	Compatibility	What it Looks Like	Side View
Acer Switch 3	Pro-Stitcher Premium		
Acer Alpha Switch 12	Pro-Stitcher Premium		
Aspire Switch 11	Pro-Stitcher Premium Pro-Stitcher Standard		
Acer W700	Pro-Stitcher Premium Pro-Stitcher Standard		
HP Omni	Pro-Stitcher Standard ProStitcher Premium is not available for this tablet – Contact your Baby Lock Retailer for options.		
Acer W500	Pro-Stitcher Standard ProStitcher Premium is not available for this tablet – Contact your Baby Lock Retailer for options.		


EEEPC	Pro-Stitcher Standard Pro-Stitcher Classic ProStitcher Premium is not available for this tablet – Contact your Baby Lock Retailer for options.		
-------	--	--	--

To check ProStitcher software version currently installed:

- In ProStitcher Standard, select Settings, Advanced, and About.
- In ProStitcher Premium, select the “?” tab, then select About.

If you already have ProStitcher Premium installed, and the version number is lower than the latest update posted, please follow these steps:

- Download the 18.02.0012 PreInstall file and the latest Premium update file.
- Install the 18.02.0012 PreInstall file following the procedures explained in the Installation Instructions.
- Restart your tablet from the desktop screen.
- Install the ProStitcher Premium update (select File tab, then select “Update” icon).



If you have ProStitcher Standard installed on a Switch 11 or Acer W700 tablet, and the version number is at 17.03.0209, please follow these steps:

- Download the 18.02.0012 PreInstall file and the latest Premium update file.
- Install the 18.02.0012 PreInstall file following the procedures explained in the Installation Instructions.

- Restart your tablet from the desktop screen.
- Install the ProStitcher Premium update (select File tab, then select “Update” icon).

If you have ProStitcher Standard installed on a Switch 11 or Acer W700 tablet, and the version number is below 17.03.0209, please follow these steps:

- Download the 17.03.0209 update file, the 18.02.0012 PreInstall file, and the latest Premium update file.
- Install the 17.03.0209 file following the procedures explained in the Installation Instructions.
- Restart your tablet from the desktop screen.
- Install the 18.02.0012 PreInstall file following the procedures explained in the Installation Instructions.
- Restart your tablet from the desktop screen.
- Install the ProStitcher Premium update (select File tab, then select “Update” icon).

If you have ProStitcher Standard installed on an EEPC, HP Omni or Acer W500 tablet, the latest update you can install is 16.01.0092.