

Baby Lock Regalia Display and Machine Software Update Instructions

From time to time Baby Lock releases a software update for our machines and displays. This update feature enables you to take advantage of the latest new capabilities added to machines and displays. When an update is released, download the updated file(s) to a USB drive using a computer that is connected to the Internet.

- Touch the **Tools** button in the Toolbar on the front display. Then touch the **Update** button along the bottom of the screen.



- After downloading the updated software to a USB drive, insert the drive in the designated USB port on the bottom-right side of the front display. Look for the message in the bottom bar that confirms a USB drive has been inserted. If it doesn't appear, reinsert the USB drive. Then touch the **Update** button. Press the **Home** button to return to the Main screen.




To update the machine's software


- ➔ **IMPORTANT:** If you are running the Regalia from a Pro-Stitcher tablet computer, the Update screen has only the machine icon because you update the machine software only. The Regalia display software is part of the Pro-Stitcher software. Make sure you are also using the latest version of Pro-Stitcher.

To update the display software


You will need to update the display on both the front and rear.

1. After inserting the USB drive into the USB port on the bottom-right side of the display, touch the display icon to update the display's software.


 **NOTE:** To update the rear display, insert the USB drive with the software into the bottom-left side of the rear display. After updating, remove the USB drive from the display.




2. You will be prompted to choose the file you want to use to update the display software. Touch the **Select Version** box and then select the filename of the update file you downloaded.



3. When the message box appears, select **New** and **Install**.



4. Be patient as this will take a few minutes.




5. Confirm that you want to overwrite the current software with the new software by choosing **Install**. If you decide to not update the software, choose **Cancel**.


 **NOTE:** Please check the Baby Lock website for the most current version (www.babylock.com)

To update the machine software


1. Insert the USB drive into the USB port on the bottom-right side of the front display. Then touch the machine icon to update the machine's software.




2. You will be prompted to choose the file you want to use to update the machine software. Touch the **Select Version** box and then select the filename of the update file you downloaded.



3. Be patient as this will take a few minutes.



4. When complete, the machine will beep. Remove the USB and restart the machine.

 **NOTE:** Please check the Baby Lock website for the most current version (www.babylock.com)