



Baby Lock Chorus (Model BLCH) Software Update Version 5.10

August 2021




Introduction

If the software version of your Chorus (Model BLCH) is earlier than version 5.10, an update program is now available for download to improve its performance.

Version 5.10 update will provide the following changes:

1. Periodic software update, does not affect consumer features.

To confirm the software version of your BLCH

1. Press the power switch to turn on your machine. The LCD screen comes on.
2. Touch anywhere on the initial screen.
3. Press  (Machine Setting Mode Key) at the bottom of the display. The settings screen appears.
4. Switch screens by using  (Previous page key) or  (Next page key) to display the software version.



5. If “**Version1**” shown in the screen is already **5.10** or later, it is not necessary to update your machine with the software on this page.

If “**Version1**” shown in the screen is lower than **5.10**, follow the procedure to update your machine.



6. Turn off machine.


How to update your machine's software

You must use a **formatted** USB Flash drive to update your machine's software.

***** NOTE *****

- Do not turn off your machine while the machine is saving the software to itself. If the machine's power is turned off while saving the software, it may result in damage to the machine.
- Use a 4GB or larger USB flash drive when installing the software to the machine.
- Check that no data except for the data file (V_V510_taco_A.upf) is saved on the **formatted** USB Flash drive, before beginning installation.

1. Insert the USB Flash drive into the USB port on the computer.
2. Copy only the update file to the USB Flash drive.
3. Safely remove the USB Flash drive from the USB port on the computer.
4. With the machine off, press the “Automatic Threading” button while turning the main power to on.



5. The following appears on the LCD screen. Press the highlighted key.

baby lock



6. Insert the USB Flash drive into the USB port on the machine.



7. Touch LOAD key.



8. Do not turn off your machine while the update file is loading.
9. When the message "Update complete." appears, the update file has been loaded.



10. Turn the machine off.
11. Remove the USB Flash drive from the USB port on the machine.
12. Turn the machine on.
13. Your machine's software has been updated to version 5.10.