

# Notice

Thank you very much for purchasing your machine.

The internal memory volume written in the machine's Instruction and Reference Guide and the actual machine is different.

## For BLTY

Page S-96 "Saving Stitch Patterns in the Machine's Memory"

**Original:** A total of about 1MB of stitch patterns can be saved in the machine's memory.

**Correct:** A total of about **511KB** of stitch patterns can be saved in the machine's memory.

Page S-98 "Saving Stitch Patterns in the Computer"

**Original:** A total of about 3MB of stitch patterns can be saved in the "Removable Disk", but the saved stitch patterns are deleted when the machine is turned OFF.

**Correct:** A total of about **772KB** of stitch patterns can be saved in the "Removable Disk", but the saved stitch patterns are deleted when the machine is turned OFF.

Page E-46 "Saving Embroidery Patterns in the Machine's Memory"

**Original:** A total of about 2MB of patterns can be saved in the machine's memory.

**Correct:** A total of about **1MB** of patterns can be saved in the machine's memory.

Page E-48 "Saving Stitch Patterns in the Computer"

**Original:** A total of about 3MB of embroidery patterns can be saved in the "Removable Disk", but the saved embroidery patterns are deleted when the machine is turned OFF.

**Correct:** A total of about **772KB** of embroidery patterns can be saved in the "Removable Disk", but the saved embroidery patterns are deleted when the machine is turned OFF.

## For BLCR

Page S-96 "Saving Stitch Patterns in the Machine's Memory"

**Original:** A total of about 1MB of stitch patterns can be saved in the machine's memory.

**Correct:** A total of about **511KB** of stitch patterns can be saved in the machine's memory.

Page S-98 "Saving Stitch Patterns in the Computer"

**Original:** A total of about 3MB of stitch patterns can be saved in the "Removable Disk", but the saved stitch patterns are deleted when the machine is turned OFF.

**Correct:** A total of about **772KB** of stitch patterns can be saved in the "Removable Disk", but the saved stitch patterns are deleted when the machine is turned OFF.

## For BLPY

Page E-46 "Saving Embroidery Patterns in the Machine's Memory"

**Original:** A total of about 2MB of patterns can be saved in the machine's memory.

**Correct:** A total of about **1MB** of patterns can be saved in the machine's memory.

Page E-48 "Saving Stitch Patterns in the Computer"

**Original:** A total of about 3MB of embroidery patterns can be saved in the "Removable Disk", but the saved embroidery patterns are deleted when the machine is turned OFF.

**Correct:** A total of about **772KB** of embroidery patterns can be saved in the "Removable Disk", but the saved embroidery patterns are deleted when the machine is turned OFF.



XG7172-001