

BABY LOCK SEWING ACCESSORIES

Flexible Seam Guide with 1/4" Foot

(BLFSG)

Instructions

Machine Settings:

Stitch	Straight stitch recommended for maximum safety
Needle Position	Center
Stitch Width	Maximum stitch width is 3.0mm

1. Attach 1/4 inch foot low shank with adapter on machine. Lower the foot.



2. Remove the clear backing and set seam guide against right side of foot. The seam guide has recessed areas on the lower side so that it sits directly over the right feed dog of the machine and over the 1/4 inch mark of the clear bobbin cover.



Note: The lower portion of the ruler can flex to curve around the bed of the sewing machine depending on the model.



3. Select the center needle position straight stitch and begin sewing, aligning the edge of the fabric along the ruler guide. The ruler on the seam guide has marks for inches and millimeters.

While standard machine feet can be used with the seam guide for decorative stitches, it is recommended that the 1/4 inch foot be used with the seam guide for better sewing performance. The 1/4 inch foot is not designed to cover the right feed dog and using this foot without the guide could cause the fabric to shift during sewing.

Note: If the blue adhesive becomes covered in lint it can be rinsed with water and air dried. This will restore the adhesive. It will be helpful to keep the clear backing and put it back on after use, to keep the blue adhesive clean.

baby lock

FOR THE LOVE OF SEWING