


BABY LOCK SEWING ACCESSORIES

Bi-Level Foot - Right

(BLSO-BRF)

Use this foot for perfect topstitching and edge stitching over seams and un-level areas. This foot is also helpful when quilting to topstitch along the edge of binding where areas may not be level. It is used for uniform and precise topstitching, and is called bi-level because the underside of the foot is designed to compensate for different thicknesses of fabric.




MACHINE SETTINGS

Stitch type:	Straight, zigzag or decorative stitch
Stitch width:	Maximum 7mm
Stitch length:	1-5mm

3. Select the desired stitch. Typically this foot is used with a straight stitch.
4. Align the fabric under the foot placing the thicker fabric on the left side and start sewing for perfect stitching.



Bottom



Instructions

1. Raise the presser foot and raise the needle to the highest position.
2. Remove the standard presser foot and attach the bi-level foot. You will notice the foot will sit crooked. This is because the underside of the foot is designed to compensate for different thicknesses of fabric.

baby lock

FOR THE LOVE OF SEWING