


Baby Lock Regalia Machine Software Update Instructions

Using ProStitcher Premium Tablet

From time to time Baby Lock releases a software update for our machines. This update feature enables you to take advantage of the latest new capabilities added to the machines.

When an update is released, download the updated file using a computer that is connected to the Internet. The update file may be zipped in a file or folder to include installation instructions. **Be sure to extract the files and save only the machine software update file to a formatted USB drive.**


Turn on the Baby Lock Regalia and the ProStitcher tablet. Allow the ProStitcher software to boot. The Regalia console screen will appear on the screen.



After downloading the updated software to a formatted USB drive, insert the drive into one of the USB ports on the left side of the tablet's bracket.




Touch the **Tools** button in the Toolbar on the Regalia console screen. Then touch the **Update** button along the bottom of the screen. The Update screen will display only the machine icon, because you will update the machine software only. The Regalia display software is part of the ProStitcher software.




Touch the machine icon to begin updating the machine's software.



File Explorer will open. Select the USB drive (Drive D), select the update file, and then select Open.



Be patient as this will take a few minutes.



When complete, the machine will beep. Remove the USB, shut down the ProStitcher tablet, and restart the machine.