

BABY LOCK SEWING ACCESSORIES

5/8" Adjustable Seam Guide Foot

(BLSA-SGF)

Instructions


Most commonly for 5/8" (16mm) garment seaming; however, this foot comes prepared to help for all your seaming needs. This foot is great for all projects that require the utmost accuracy, such as: garment seam allowances, topstitching or piecing while quilting. The built-in ruler and guide are helpful for keeping your measurements precise at all times.

Instructions:

1. Remove the all-purpose foot. Attach the 5/8" guide foot to presser foot holder.
2. Select a straight stitch, zigzag or decorative stitch. For garment seams, use a center needle position and select a straight stitch.

Seam Allowances and Recommendations:

- 3/8" (10mm) – Some Children's Clothing and Doll Clothing
 - 1/2" (12.7mm) – Home Décor and Craft Projects
 - 5/8" (16mm) – Garment Sewing
 - 1" (25mm) – Garment tailoring and Hems
3. The notches along the guide bar secure the adjustable guide to the width you set.



4. When turning corners, stop with the needle down in the fabric and pivot the fabric, raise the presser foot, to check alignment. On foot itself there is a red marking guide down middle of foot and red marking guides on either side.
5. When sewing curves, use the edge of the guide to follow the edge of the fabric. The guide allows the fabric to smoothly feed into the machine and easier guiding of the fabric around the curve for accurate curved seaming.
6. When using pins, always remove them before they reach the foot.



FOR THE LOVE OF SEWING

5/8 pouce (16mm) Pied guide réglable

(BLSA-SGF)

Instructions


Le plus souvent pour les coutures de vêtement de 5/8 pouce (16mm), cependant, ce pied est préparé pour répondre à tous vos besoins en matière de couture. Ce pied est idéal pour tous les projets nécessitant la plus grande précision, tels que les surplus de couture de vêtement, les surpiqûres ou les piqûres pendant le matelassage. La règle et le guide intégrés sont pratiques pour garder vos mesures précises à tout moment.

Instructions:

1. Retirez le pied universel. Fixez le pied guide 5/8 pouce (16mm) à la bride semelle.
2. Sélectionnez un point droit, un point zigzag ou décoratif. Pour les coutures des vêtements, utilisez une position d'aiguille centrale et sélectionnez un point droit.

Coutures et recommandations:

- 3/8 pouce (10mm) - Certains vêtements pour enfants et vêtements de poupée
 - 1/2 pouce (12.7mm) - Décors pour la maison et projets artisanaux
 - 5/8 pouce (16mm) - Couture de vêtement
 - 1 pouce (25mm) - Couture de vêtement et ourlets
3. Les encoches situées le long de la barre de guidage fixent le guide réglable à la largeur souhaitée.



4. En tournant les coins, arrêtez l'aiguille dans le tissu, relevez le pied de biche et pivotez le tissu et vérifiez son alignement.

Le pied guide réglable de 5/8 pouce (16mm) a un guide de marquage rouge au centre du pied et de chaque côté du pied.

5. Lorsque vous cousez des courbes, utilisez le bord du guide pour suivre le bord du tissu. Le guide permet au tissu de suivre la courbe de couture souhaitée.
6. Lorsque vous utilisez des épingles, retirez toujours les aiguilles avant qu'elles n'atteignent le pied.