



# **Baby Lock Venture (Model BMVT10) Software Update Version 1.01**

September 2020


## **Introduction**

If the software version of your Venture (Model BMVT10) is earlier than version 1.01, an update program is now available for download to improve its performance.

## **Version 1.01 update will provide the following changes:**


1. Revised built-in tutorial videos.
2. Improved search capability for embroidery positioning sticker with the built-in camera.
3. Improved editing character functionality.
4. Revised messages.
5. Improved embroidering quality when optional magnetic sash frame\* is attached.  
\* The accessory is sold separately.

## **To confirm the software version of your BMVT10**

1. Press the power switch to turn on your machine. The LCD screen comes on.
2. Touch anywhere on the initial screen, and then touch “OK”.
3. Touch  (Settings key) at the bottom of the display. The Settings screen appears.



4. Switch screens by using  and  to display the software version.



5. If the version shown on your machine is already Version 1.01 or later, it is not necessary to update your machine with the program on this page.

## How to download the update program

1. Click the Details link on the web page for your machine. Click on the Manuals and Updates link, then select Download to download the Version 1.01 zipped update file.
2. Right-click on the downloaded zipped update file, select “Extract All”, and follow the steps to extract the files. There will be two extracted files: these instructions and the actual update file (PR3\_V101\_TP.upf, size: 76.4 MB).

## How to update your machine’s software


You can use a formatted USB Flash drive to update your machine's software.

### **\*\*\* NOTE \*\*\***


- Do not turn off your machine while the machine is saving the software to itself. If the machine's power is turned off while saving the software, it may result in damage to the machine.
- Use a 4GB or larger USB flash drive when installing the software to the machine.
- Check that no data except for the video data file (PR3\_V101\_TP.upf) is saved on the **formatted** USB Flash drive, before beginning installation.



1. Insert the USB Flash drive into the USB port on the computer.
2. Copy the update file to the USB Flash drive.
3. Safely remove the USB Flash drive from the USB port on the computer.
4. With the machine off, press the automatic threading button while turning the main power to on.




5. The following screen appears on the LCD. Touch the USB media key.



(The screen varies depending on the software version on your machine.)

6. Insert the USB Flash drive into the USB port on the machine.






7. Touch LOAD key.



8. When the message "Upgrade complete" appears, the update file has been loaded.



9. Turn the machine off.
10. Remove the USB Flash drive from the USB port on the machine.
11. Turn the machine on.
12. Your machine's software has been updated to version 1.01.