



Baby Lock Vesta (Model BLMVE) Software Update Version 1.02

August 2021


Introduction


If the software version of your Vesta (Model BLMVE) is earlier than version 1.02, an update program is now available for download to improve its performance.

Version 1.02 update will provide the following changes:

1. Revised messages for the following languages:
French, Danish, Norwegian, Finnish, Swedish, Polish, Czech, Romanian, Russian, Korean

To confirm the software version of your BLMVE

2. Press the power switch to "|" to turn on your machine.
3. Press  (Settings key) to display the machine's settings screen.
4. Switch the settings screens by using ◀ (Previous page key) or ▶ (Next page key) to display the machine's program version.



5. If the "Version" shown in the screen is already "1.02" or later, it is not necessary to update your machine with the program on this page.



How to download the update program

1. Click the Details link on the web page for your machine. Click on the Manuals and Updates link, then select Download to download the Version 1.02 update file.
2. Right-click on the downloaded zipped update file, select “Extract All”, and follow the steps to extract the files. There will be two extracted files: these instructions and the actual update file (FWCTE1A102.upf, size: 25.3 MB).


How to update your machine's software

You can use a **formatted** USB Flash drive to update your machine's software.

***** NOTE *****


- Do not turn off your machine while the machine is saving the software to itself. If the machine's power is turned off while saving the software, it may result in damage to the machine.
- Use a 4GB or larger USB flash drive when installing the software to the machine.
- Check that no data except for the data file (FWCTE1A102.upf) is saved on the **formatted** USB Flash drive, before beginning installation.

1. Insert the USB Flash drive into the USB port on the computer.
2. Copy the update file to the USB Flash drive.
3. Safely remove the USB Flash drive from the USB port on the computer.
4. With the machine off, press the “Presser Foot Lift” button while turning the main power to on.







5. The following screen appears on the LCD.



6. Insert the USB Flash drive into the USB port on the machine.




7. Touch LOAD key.






8. The following screen appears on the LCD. Do not turn off your machine while the machine is saving the update software to itself.



9. When the message "Update complete." appears, the update file has been loaded.



10. Turn the machine off.
11. Remove the USB Flash drive from the USB port on the machine.
12. Turn the machine on.
13. Your machine's software has been updated to version 1.02.