



Baby Lock Aventura II (Model BLMAV2) Software Update Version 1.31

October 2022




Introduction

If the software version of your Aventura II (Model BLMAV2) is earlier than version 1.31, an update program is now available for download to improve its performance.

Version 1.31 update will provide the following changes:

1. Improved machine's functionality for sewing reinforcement stitches.
2. Improved the thread color palette screen when using a pattern data that contains the embroidery thread brands that are not defined in the embroidery machine.
3. The foot control communication with the machine has been optimized.
4. Improved machine's functionality for displaying the maintenance message.

To confirm the software version of your BLMAV2

1. Press the power switch to "I" to turn on your machine.
2. Press  (Settings key) to display the machine's settings screen.
3. Switch the settings screens by using  (Previous page key) or  (Next page key) to display the machine's program version.
4. If the "Version" shown in the screen is already "1.31" or later, it is not necessary to update your machine with this software version.





How to update your machine's software

You can use a **formatted** USB flash drive to update your machine's software.


*** NOTE ***

- Do not turn off your machine while the machine is saving the update software to itself. If the machine's power is turned off while saving the update software, it may result in damage to the machine.
- Use a 4GB to 8 GB USB flash drive when updating the machine.
- Check that no data is saved on the **formatted** USB flash drive, before beginning update.

1. Insert the USB Flash drive into the USB port on the computer.
2. Copy only the update file, FCBTE1A131.upf to the USB Flash drive.
3. Safely remove the USB Flash drive from the USB port on the computer.
4. Turn on your machine while pressing and holding  (Presser foot lifter button).




5. The following screen appears on the LCD.







6. Insert the USB flash drive into the USB port on the machine.




7. Touch LOAD key.



8. The following screen appears on the LCD. Do not turn off your machine while the machine is saving the update software to itself.



9. When the following screen appears, updating is completed.



10. Remove the USB flash drive and turn the machine off and on again.
11. The machine's software has been updated to version 1.31.



Baby Lock Aventura II (BLMAV2) Update History

Version 1.30 update provided the following changes:

1. The optional magnetic frame EMF180 can be recognized on the machine.

Version 1.26 update provided the following changes:

1. The foot control communication with the machine has been optimized.

Version 1.22 update provided the following changes:

1. Revised the wording of messages.

Version 1.21 update provided the following changes:

1. Revised the wording of messages.